

CRUISE CONTROL SYSTEM

8510-23

OVERVIEW AND OPERATION PROCESS

1. CRUISE CONTROL SWITCH



The purpose of the cruise control system is to automatically maintain a vehicle speed set by the driver, without depressing the accelerator pedal. The cruise control switch is located under the right side of the steering wheel, and when this switch is operating "AUTO CRUISE" lamp comes on.

The minimum speed for setting the cruise control system is 36 km/h (22.37 mph). Pay constant attention to the distance between the vehicles and the traffic conditions when using the cruise control system.

CAUTION

The cruise control system is a supplementary system, which helps the driver to drive the vehicle at a desired speed without using the accelerator pedal under the traffic condition where the vehicle-to-vehicle distance meets the legal requirement.

Modification basis	
Application basis	
Affected VIN	

1) When To Use

Use the cruise control system only when (a) the traffic is not jammed, (b) driving on motorways or highways where there is no sudden change in the driving condition due to traffic lights, pedestrian, etc.


WARNING

Use the cruise control system only when driving on motorways or highways. Do not use the cruise control system where the road conditions are as follows:


- When there is strong wind or cross wind.
- Heavy traffic.
- Slippery roads or steep decline.

Modification basis	
Application basis	
Affected VIN	

2. CIRCUIT DIAGRAM



1) Configuration



Modification basis	
Application basis	
Affected VIN	

3. HOW TO OPERATE CRUISE CONTROL SWITCH

1) How To Set Speed



1. To operate the cruise control system, accelerate the vehicle to the speed within the specified range below with depressing the accelerator pedal.
 - Cruise control operating range: between 36 km/h (22.37 mph) and 150 km/h (93.207 mph)
2. When the desired speed is reached, which should be within the above range, push up the cruise control switch lever to ACCEL side (upwards arrow), or push down the switch lever to DECEL side (downwards arrow).
3. Now the vehicle is cruised by this system with the set speed. You don't need to use the accelerator pedal.
4. Refer to the following pages for details of operation.


⚠ CAUTION

Never use the cruise control system until you get used to it.

Improper use or not fully aware of this function could result in collision and/or personal injuries.

Modification basis	
Application basis	
Affected VIN	

2) Accelerating with the Cruise Control System



(1) While the cruise control system is running

1. To increase the set speed, push up the cruise control switch lever to ACCEL side and hold it until the desired speed is reached without depressing the accelerator pedal.
2. When the desired speed is set, release the switch lever.

(2) When the cruise control system is not running

To increase the speed with the cruise control system while the system is not running, follow the procedures below.

1. Accelerate the vehicle to more than 36 km/h (22.37 mph) using the accelerator pedal. Push up the cruise control switch lever to ACCEL side and hold it.
2. When the desired speed is reached, release the accelerator pedal and the switch lever.


(3) Tap-up while the cruise control system is running

To increase the vehicle speed in stages while the cruise control system is running, follow the procedures below.

1. Push up the cruise control switch lever to ACCEL side for less than 0.5 second per one switching while the cruise control system is running; the speed increases each time by 1.3 km/h (0.81 mph).
2. For example, if you want to increase the speed 13 km/h (8.1 mph) more than the previous set speed, tap up the switch lever to ACCEL side ten times without using the accelerator pedal.

Modification basis	
Application basis	
Affected VIN	

3) Decelerating with the Cruise Control System



(1) While the cruise control system is running

1. To decrease the set speed, push down the cruise control switch lever to DECEL side and hold it until the desired speed is reached without depressing the brake pedal.
But the cruise control system cannot maintain the cruise function at less than 34 km/h (21.13 mph).
2. When the desired speed is set, release the switch lever.

(2) When the cruise control system is not running

To decrease the speed with the cruise control system while the system is not running, follow the procedures below.

1. Push down the cruise control switch lever to DECEL side and hold it until the desired speed is reached while the vehicle speed is over 36 km/h (22.37 mph).
2. When the desired speed is reached, release the switch lever.
3. But the cruise control system cannot maintain the cruise function at less than 34 km/h (21.13 mph).

(3) Tap-down while the cruise control system is running

To decrease the vehicle speed in stages while the cruise control system is running, follow the below procedures.

1. Push down the cruise control switch lever to DECEL side for less than 0.5 second per one switching while the cruise control system is running; the speed decreases each time by 1.0 km/h (0.62 mph).
2. For example, if you want to decrease the speed 10 km/h (6.2 mph) lower than the previous set speed, tap down the switch lever to DECEL side ten times without using the brake pedal.

Modification basis	
Application basis	
Affected VIN	

4) Recovery of Set Speed (RESUME)



Even if the cruise control is cancelled, the previous set cruise speed can be recovered by operating the cruise control switch lever like below:

- Pull the switch lever in the arrow direction shown in the illustration.


This RESUME function works only when the vehicle speed is more than 36 km/h (22.37 mph) without using the accelerator or brake pedal.

⚠ CAUTION

But the driver should know the previous set speed to react to the changed vehicle speed properly. If the vehicle speed increases abruptly, depress the brake pedal to adjust the vehicle speed properly.

Modification basis	
Application basis	
Affected VIN	

5) Normal Cancellation of the Cruise Control (OFF ↔ ON)



The cruise control system will be cancelled when the button on the side of the switch is pressed, or when one of the following conditions is met:

1. When the brake pedal is depressed or ESP is activated.
2. When the vehicle speed is less than 34 km/h (21.13 mph).
3. When the parking brake is applied while driving.
4. When the clutch pedal is depressed for shifting (M/T only).

CAUTION

Put the cruise control switch lever in the neutral position when not using the cruise control system.

(1) Abnormal Cancellation of the Cruise Control

1. When the rapid deceleration or acceleration occurs.
2. When the cruise control lever is faulty.
3. When the brake switch is malfunctioning or has an open circuit.

When the cruise control function is cancelled abnormally or intermittent problems occur, stop the vehicle and turn off the ignition switch and remove the key to reset the system. After a while, turn on the ignition switch again to operate the cruise control system.

CAUTION

- Do not move the shift lever to Neutral position while driving with the cruise control turned on. Otherwise, it may result in system malfunction or accidents.
- Always be prepared to use the brake or accelerator pedal for safe driving while the cruise control system is running.
- The actual speed can be different from the set speed momentarily when driving on a uphill or downhill. So, it is recommended to disable the cruise control function on a uphill or downhill. When driving on a steep hill use the engine brake and foot brake properly to protect the vehicle system and for a safe driving.
- Ensure that the braking distance is maintained and use the brake pedal if needed.

Modification basis	
Application basis	
Affected VIN	